



## Instructions | Part#: RD-5-8043-27-0P

For Red Dot R-5075 units.

### Installation instructions for R-5075 units cable converter retro-fit,

1. Remove knobs from cable converters and unplug wire harnesses from switches.
2. Remove cable converters from cover.
3. Trim gasket on cover to allow adapter plate to mate against metal cover
4. Install adapter plate and cable converters onto cover using jam nuts. (Torque to 20-25 in-lbs)
5. Install knobs on cable converters and reconnect wire harnesses to switches. (See switch wiring schematic)
6. Install shorter control cable on left cable converter.
7. Install shorter control cable on right cable converter.
8. Route shorter cable to water valve.
9. Route longer cable to fresh air door.
10. Re-install cover on unit.

