



Instructions | Part#: 4-58440

John Deere, Condenser Add on Kit

Fits John Deere Models: 8440, 8640 Tractor

1. Evacuate the A.C system.
2. Slide the original condenser out for easier access.
3. Disconnect the # 6 high side line from the original condenser.
4. Install hose included in kit with # 6 fitting from original condenser to # 8 larger fitting on the auxillary condenser.
NOTE: Before installing any lines add 1-2 oz.of pag or ester oil to auxillary condenser.
5. Attach auxillary condenser to the front side of original condenser with mounting straps included in the kit.
Mount condenser as low as possible-covering the least amount of oil cooler. (Refer to picture below)
6. Reconnect original # 6 hose to adapter hose on auxillary condenser. *(Refer to picture below)*
7. Vacuum down system and recharge to estimated capacity of 3lbs - 3.5lbs.

